



**CAUTION:** The coals are extremely fragile and must be handled accordingly. Gloves should be worn and any inhalation of dust should be avoided. The coals must be kept away from children at all times. Never put additional coals on the fire. Never use coals other than those originally supplied, or genuine Legend Spare Parts.




Fig. 13



Fig. 14

1. Place the main fuel bed on to the back section of the metal burner tray. It is important that the front edge of the fuel bed is located behind the burner strip, and the holes in the fuel bed line up with the holes in the Burner tray (Fig. 14).



Fig. 15

3. Position the front coal piece on the front coal retainer, making sure that the back edge is pushed up against the front of the burner strip (Fig. 15).

4. Locate the remaining coal pieces in order as shown in Figs. 16 & 17.



Fig. 16



Fig. 17



5. Finally check that all the coal pieces are 'nested' together correctly (Fig. 18) and a close fit is achieved on the middle joint (this will stop gas surge through the gap).



**Fig. 18**

**It is very important that all the coals are used and arranged as shown in order to achieve the desired flame picture.**

It may be necessary to remove some or all of the coals to clean them at some time.  
Cleaning must only be done using a soft brush.