



**It is very important that all the coals are used and arranged as shown in order to achieve the desired flame picture.**

It may be necessary to remove some or all of the coals to clean them at some time. Cleaning must only be done using a soft brush.

**CAUTION:** The coals are extremely fragile and must be handled accordingly. Gloves should be worn and any inhalation of dust should be avoided. The coals must be kept away from children at all times. Never put additional coals on the fire. Never use coals other than those originally supplied, or genuine Legend Spare Parts.

1. Place the main fuel bed on to the back section of the metal burner tray. It is important that the front edge of the fuel bed is located behind the burner strip (Fig. 8).

2. Position the front coal on the front coal retainer, making sure that the back edge is pushed up against the front of the burner strip (Fig. 9).

3. Lay the first row of six loose coals on top of the front coal, with the back of the coals resting against the fuel bed ensuring even gaps all round (Fig. 10).



Fig. 11

4. Choose five loose coals and place them in line on the next row up, again making sure all the gaps are even. It is important that the coals 'bridge' the peaks of the fuel bed and are not placed in between them (Fig. 11).

5. Place the next four coals randomly on the back edge of the coals previously laid. Make any adjustments necessary to achieve even gaps as this will help in giving a well balanced flame picture and an even red glow (Fig. 12).



Fig. 12